










Assembly Instruction for Drawer Unit To Worktop & Heavy Duty Frame

- A.  M8x15 x 8 pcs
- B.  M8 x 12 pcs
- C.  Ø8.5 x 22 pcs
- D.  Wrench 13 x1pcs
- E.  W.S Ø6 x30 x6 pcs
- F.  W. Ø6.5 x6pcs
- G.  M8x25 x6pcs
- H.  Key 6& key4 x2pcs
- I.  M 8x15 x4pcs

